



Table of Contents

1	Important information	_ 4
	Safety information	_ 4
2	Delivery and handling	_ 10
	Transport and storage	_ 10
	Assembly	_ 10
	Condensation	_ 12
	Installation area	_ 14
	Supplied components	_ 14
	Removing the side cover	_ 15
3	The heat pump design	16
	General	_ 16
	Distribution box	_ 20
4	Pipe connections	_ 21
	General	_ 21
	Pipe coupling heating medium circuit	_ 21
	Pressure drop, heating medium side	_ 21
	Heat insulation	_ 21
	Installing flex hoses	_ 22
5	Electrical connections	_ 23
	General	_ 23
	Accessibility, electrical connection	_ 24
	Configuration using dip switch	_ 25
	Connections	_ 26
	Optional connections	_ 29
	Connecting accessories	_ 30
6	Commissioning and adjusting	_ 31
	Preparations	_ 31
	Filling and venting the heating medium sys- tem	_ 31
	Start-up and inspection	_ 31
	Readjusting, heating medium side	_ 31
	Adjustment, charge flow	_ 32
7	Control - Introduction	_ 33
	General	_ 33
	LED status	_ 33
	Master control	_ 33
	Control conditions	_ 34
	Control - Heat pump EB101	_ 35
8	Disturbances in comfort	_ 36
	Troubleshooting	_ 36

9	Accessories	39
10	Technical data	40
	Dimensions	40
	Sound pressure levels	41
	Technical specifications	42
	Working area	46
	Heating	48
	Cooling	50
	Energy labelling	51
	Electrical circuit diagram	55

Index	 63

1 Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. The product is intended for use by experts or trained users in shops, hotels, light industry, farming and similar environments.

Children must be instructed/supervised to ensure that they do not play with the appliance.

Do not allow children to clean or maintain the appliance unsupervised.

This is an original manual. It may not be translated without the approval of NIBE.

We reserve the right to make design modifications without prior notice.

©NIBE 2016.

Balance temperature

The balance temperature is the outdoor temperature when the heat pump's stated output is equal to the building's output requirement. This means that the heat pump covers the whole building's output requirement down to this temperature.

Stop temperature

If the ambient temperature is below the stop temperature, heating must occur with additional heat.

Compressor heater

F2120 is equipped with two compressor heaters that heat the compressor before start-up and when the compressor is cold.

NOTE

The compressor heater must have been active for approx. 3 hours before the first start, see section "Start-up and inspection" on page 31.

Symbols

NOTE

This symbol indicates danger to machine or person.

Caution

This symbol indicates important information about what you should observe when maintaining your installation.

This symbol indicates tips on how to facilitate using the product.

Marking

The CE marking means that NIBE ensures that the product meets all regulations that are placed on it based on relevant EU directives. The CE mark is obligatory for most products sold in the EU, regardless where they are made.

Serial number

The serial number can be found at the top left on the rear.



Section

Always give the product's serial number when reporting a fault.

Recovery



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

Do not dispose of used products with normal household waste. It must be disposed of at a special waste station or dealer who provides this type of service.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

Country specific information

Installer manual

This installer manual must be left with the customer.

Safety precautions

Caution

Install the system in full accordance with this installation manual.

Incorrect installation can cause bursts, personal injury, water leaks, refrigerant leaks, electric shocks and fire.

Observe the measurement values before working on the cooling system, especially when installing in small rooms, so that the limit for the refrigerant's density is not exceeded.

Consult an expert to interpret the measurement values. If the refrigerant density exceeds the limit, lack of oxygen can occur in the event of any leak, which can cause serious accidents.

Use original accessories and the stated components for the installation.

If parts other than those stated by us are used, water leaks, electric shocks, fire and personal injury may occur as the unit may not work properly.

Ventilate the working area well – refrigerant leakage may occur during service work.

If the refrigerant comes into contact with naked flames, poisonous gas is created.

Install the unit in a location with good support.

Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury. Installation without sufficient support can also cause vibrations and noise.

Ensure that the unit is stable when installed, so that it can withstand earthquakes and strong winds.

Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.

The electrical installation must be carried out by a qualified electrician and the system must be connected as a separate circuit.

Power supply with insufficient capacity and incorrect function can cause electric shocks and fire.

Use the stated cables for the electrical connection, tighten the cables securely in the terminal blocks and relieve the wiring correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause abnormal heat production or fire.

Check, after completed installation or service, that no refrigerant leaks from the system in gas form.

If refrigerant gas leaks into the house and comes into contact with an aerotemp, an oven or other hot surface, poisonous gases are produced.

Switch off the compressor before opening/breaching the refrigerant circuit.

If the refrigerant circuit is breached /opened whilst the compressor is running, air can enter the process circuit. This can cause unusually high pressure in the process circuit, which can cause bursts and personal injury.

Switch off the power supply in the event of a service or inspection.

If the power supply is not shut off, there is a risk of electric shocks and damage due to the rotating fan.

Do not run the unit with removed panels or protection.

Touching rotating equipment, hot surfaces or high voltage parts can cause personal injury due to entrapment, burns or electric shocks.

Cut the power before starting electrical work.

Failure to cut the power can cause electric shocks, damage and incorrect function of the equipment.

Care

Carry out the electrical installation with care.

Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.

Use main switch with sufficient breaking capacity.

If the switch does not have sufficient breaking capacity, malfunctions and fire can occur.

Always use a fuse with the correct rating in the locations where fuses are to be used.

Connecting the unit with copper wire or other metal thread can cause unit breakdown and fire.

Cables must be routed so that they are not damaged by metal edges or trapped by panels.

Incorrect installation can cause electric shocks, heat generation and fire.

Do not install the unit in close proximity to locations where leakage of combustible gases can occur.

If leaking gases collect around the unit, fire may occur.

Do not install the unit where corrosive gas (for example nitrous fumes) or combustible gas or steam (for example thinner and petroleum gases) can build up or collect, or where volatile combustible substances are handled.

Corrosive gas can cause corrosion to the heat exchanger, breaks in plastic parts etc. and combustible gas or steam can cause fire.

Do not use the unit where water splashes may occur, for example in laundries.

The indoor section is not waterproof and electric shocks and fire can therefore occur.

Do not use the unit for specialist purposes such as for storing food, cooling precision instruments, freeze-conservation of animals, plants or art.

This can damage the items.

Do not install and use the system close to equipment that generates electromagnetic fields or high frequency harmonics.

Equipment such as inverters, standby sets, medical high frequency equipment and telecommunications equipment can affect the unit and cause malfunctions and breakdowns. The unit can also affect medical equipment and telecommunications equipment, so that it functions incorrectly or not at all.

Do not install the outdoor unit in the locations stated below.

Locations where leakage of combustible gas can occur.
 Locations where carbon fibre, metal powder or other powder that can enter the air.

- Locations where substances that can affect the unit, for example, sulphide gas, chlorine, acid or alkaline substances can occur.

- Locations with direct exposure to oil mist or steam.
- Vehicles and ships.

- Locations where machines that generate high frequency harmonics are used.

- Locations where cosmetic or special sprays are often used.

- Locations that can be subjected to direct salty atmospheres. In this case, the outdoor unit must be protected against direct intakes of salty air.

- Locations where large amounts of snow occur.
- Locations where the system is exposed to chimney smoke.

If the bottom frame of the outdoor section is corroded, or in any other way damaged, due to long periods of operation, it must not be used.

Using an old and damaged frame can cause the unit to fall and cause personal injury.

If soldering near the unit, ensure that solder residue does not damage the drip tray.

If solder residue enters the unit during soldering, small holes can appear in the tray resulting in water leakage. To prevent damage, keep the indoor unit in its packing or cover it.

Do not allow the drainage pipe to exit into channels where poisonous gases, containing sulphides for example, can occur.

If the pipe exits into such a channel, any poisonous gases will flow into the room and seriously affect the user's health and safety.

Insulate the unit's connection pipes so that the ambient air moisture does not condense on them.

Insufficient insulation can cause condensation, which can lead to moisture damage on the roof, floor, furniture and valuable personal property.

Do not install the outdoor unit in a location where insects and small animals can inhabit.

Insects and small animals can enter the electronic parts and cause damage and fire. Instruct the user to keep the surrounding equipment clean.

Take care when carrying the unit by hand. If the unit weights more than 20 kg, it must be carried by two people. Use gloves to minimize the risk of cuts.

Dispose of any packaging material correctly.

Any remaining packaging material can cause personal injury as it may contain nails and wood.

Do not touch any buttons with wet hands. This can cause electric shocks.

Do not touch any refrigerant pipes with your hands when The system is in operation. During operation the pipes become extremely hot or extremely

cold, depending on the method of operation. This can cause burn injuries or frost injuries.

Do not shut off the power supply immediately after operation has start.

Wait at least 5 minutes, otherwise there is a risk of water leakage or breakdown.

Do not control the system with the main switch. This can cause fire or water leakage. In addition, the fan can start unexpectedly, which can cause personal injury.

Especially for units intended for R410A

- Do not use other refrigerants than R410A. R410A means that the pressure is about 1.6 times as high as conventional refrigerants.

- Do not use charging bottles. These types of bottles change the composition of the refrigerant, which makes the performance of the system worse.

- When filling refrigerant, the refrigerant must always leave the bottle in liquid form.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. Fill in the page for information about installation data in the User manual.

~	Description	Notes	Signature	Date
Heating medium (side 21)				
	System flushed			
	System vented			
	Particle filter			
	Shut-off and drain valve			
	Charge flow set			
Pow	ver (page 23)			
	Fuses property			
	Safety breaker			
	Earth circuit-breaker			
	Heating cable type/effect			
	Fuse size, heating cable (F3)			
	Communication cable connected			
	F2120 addressed (only when cascade connection)			
	Connections			
	Main voltage			
	Phase voltage			
Mise	cellaneous			
	Condensation water pipe			
	Insulation condensation water pipe, thickness (if KVR 10 is not used)			

NOTE

Check the connections, main voltage and phase voltage before the machine is started, to prevent damage to the heat pump electronics.

Contact information

- AT KNV Energietechnik GmbH, Gahberggasse 11, 4861 Schörfling Tel: +43 (0)7662 8963-0 Fax: +43 (0)7662 8963-44 E-mail: mail@knv.at www.knv.at
- CH NIBE Wärmetechnik c/o ait Schweiz AG, Industriepark, CH-6246 Altishofen Tel: (52) 647 00 30 Fax: (52) 647 00 31 E-mail: info@nibe.ch www.nibe.ch
- CZ Druzstevni zavody Drazice s.r.o, Drazice 69, CZ 294 71 Benatky nad Jizerou Tel: +420 326 373 801 Fax: +420 326 373 803 E-mail: nibe@nibe.cz www.nibe.cz
- **DE NIBE Systemtechnik GmbH**, Am Reiherpfahl 3, 29223 Celle
- Tel: 05141/7546-0 Fax: 05141/7546-99 E-mail: info@nibe.de www.nibe.de **DK Vølund Varmeteknik A/S**, Member of the Nibe Group, Brogårdsvej 7, 6920 Videbæk
 - Tel: 97 17 20 33 Fax: 97 17 29 33 E-mail: info@volundvt.dk www.volundvt.dk
- FINIBE Energy Systems OY, Juurakkotie 3, 01510 VantaaPuh: 09-274 697 0 Fax: 09-274 697 40 E-mail: info@nibe.fi www.nibe.fi
- **FR** NIBE Energy Systems France Sarl, Zone industrielle RD 28, Rue du Pou du Ciel, 01600 Reyrieux Tel : 04 74 00 92 92 Fax : 04 74 00 42 00 E-mail: info@nibe.fr www.nibe.fr
- **GB** NIBE Energy Systems Ltd, 3C Broom Business Park, Bridge Way, Chesterfield S41 9QG Tel: 0845 095 1200 Fax: 0845 095 1201 E-mail: info@nibe.co.uk www.nibe.co.uk
- NL NIBE Energietechniek B.V., Postbus 634, NL 4900 AP Oosterhout Tel: 0168 477722 Fax: 0168 476998 E-mail: info@nibenl.nl www.nibenl.nl
- NO ABK AS, Brobekkveien 80, 0582 Oslo, Postadresse: Postboks 64 Vollebekk, 0516 Oslo Tel. sentralbord: +47 23 17 05 20 E-mail: post@abkklima.no www.nibeenergysystems.no
- PL NIBE-BIAWAR Sp. z o. o. Aleja Jana Pawła II 57, 15-703 BIAŁYSTOK Tel: 085 662 84 90 Fax: 085 662 84 14 E-mail: sekretariat@biawar.com.pl www.biawar.com.pl
- **RU** © **"EVAN"** 17, per. Boynovskiy, Nizhny Novgorod Tel./fax +7 831 419 57 06 E-mail: info@evan.ru www.nibe-evan.ru
- SE NIBE AB Sweden, Box 14, Hannabadsvägen 5, SE-285 21 Markaryd Tel: +46-(0)433-73 000 Fax: +46-(0)433-73 190 E-mail: info@nibe.se www.nibe.se

For countries not mention in this list, please contact Nibe Sweden or check www.nibe.eu for more information.

2 Delivery and handling

Transport and storage

F2120 must be transported and stored vertically.

NOTE

Ensure that the heat pump cannot fall over during transport.

Ensure that the heat pump cannot be damaged during transportation.

Assembly

- Place F2120 outdoors on a solid level base that can take the weight, preferably a concrete foundation.
 If concrete slabs are used they must rest on asphalt or shingle.
- The concrete foundation or slabs must be at least 70 mm high so that the lower edge of the evaporator is at the level of the average local snow depth, however a minimum height of 300 mm.
- F2120 should not be positioned next to noise sensitive walls, for example, next to a bedroom.
- Also ensure that the placement does not inconvenience the neighbours.
- F2120 must not be placed so that recirculation of the outdoor air can occur. This causes lower output and impaired efficiency.
- The evaporator must be sheltered from direct wind /, which negatively affects the defrosting function.
 Place F2120 protected from wind / against the evaporator.
- Large amounts of condensation water, as well as melt water from defrosting, can be produced. Condensation water must be led off to a drain or similar (see page 12).
- Care must be exercised so that the heat pump is not scratched during installation.



Do not place F2120 directly on the lawn or other non solid surface.



If there is a risk of snow slip from roof, a protective roof or cover must be erected to protect the heat pump, pipes and wiring.

Lift from the street to the set up location

If the base allows, the simplest thing is to use a pallet truck to move the F2120 to the set up location.



If F2120 needs to be transported across soft ground, such as a lawn, we recommend that a crane is used that can lift the unit to the installation location. When F2120 is lifted with a crane, the packaging must be undisturbed, see the illustration above.

If a crane vehicle cannot be used the F2120 can be transported on an extended sack truck. F2120 must be taken from its heaviest side and two people are required to lift F2120.

Lift from the pallet to final positioning

Before lifting remove the packaging and the securing strap to the pallet.

Place lifting straps around each machine foot. Lifting from the pallet to the base requires four persons, one for each lifting strap.

Scrapping

When scrapping, the product is removed in reverse order. Lift by the bottom panel instead of a pallet!

Condensation

The condensation water trough collects and leads away most of the condensation water from the heat pump.

NOTE

It is important to the heat pump function that condensation water is led away and that the drain for the condensation water run off is not positioned so that it can cause damage to the house.

NOTE

Pipe with heating cable for draining the condensation water trough is not included.

NOTE

To ensure this function the accessory KVR 10 should be used.

NOTE

Condensation runoff should be checked regularly, especially during the autumn. Clean if necessary.

NOTE

- The electrical installation and wiring must be carried out under the supervision of an authorised electrician.
- The condensation water (up to 50 litres/24 hrs) that collects in the trough should be routed away by a pipe to an appropriate drain, it is recommended that the shortest outdoor stretch possible is used.
- The section of the pipe that can be affected by frost must be heated by the heating cable to prevent freezing.
- Route the pipe downward from F2120.
- The outlet of the condensation water pipe must be at a depth that is frost free or alternatively indoors (with reservation for local ordinances and regulations).
- Use a water trap for installations where air circulation may occur in the condensation water pipe.
- The insulation must seal against the bottom of the condensation water trough.

Recommended alternative for leading off condensation water

Stone caisson



If the house has a cellar the stone caisson must be positioned so that condensation water does not affect the house. Otherwise the stone caisson can be positioned directly under the heat pump.

The outlet of the condensation water pipe must be at frost free depth.

Drain indoors



The condensation water is lead to an indoor drain (subject to local rules and regulations).

Route the pipe downward from F2120.

The condensation water pipe must have a water seal to prevent air circulation in the pipe.

KVR 10 spliced as illustrated. Pipe routing inside house not included.

Gutter drainage



The outlet of the condensation water pipe must be at frost free depth.

Route the pipe downward from F2120.

The condensation water pipe must have a water seal to prevent air circulation in the pipe.

Caution

If none of the recommended alternatives is used good lead off of condensation water must be assured.

Installation area

The distance between F2120 and the house wall must be at least 350 mm. Clearance above F2120 should be at least 1,000 mm. However, free space in front must be 1,000mm for future servicing.



Supplied components

Enclosed components for F2120





4 seals

Particle filterR32

Removing the side cover



3 The heat pump design

General

F2120 (1x230V)



F2120 (3x400V)





Pipe connections

- XL1 Connection, heating medium out of F2120
- XL2 Connection, heating medium in to F2120,
- XL20 Service connection, high pressure
- XL21 Service connection, low pressure
- XL40 Connection, drain condensation water trough

Sensors etc.

- BP1 High pressure pressostat
- BP2 Low pressure pressostat
- BP8 Low pressure transmitter
- BP9 High pressure sensor
- BP11 Pressure sensor, injection
- BT3 Temperature sensor, return
- BT12 Temperature sensor, condenser supply line
- BT14 Temperature sensor, hot gas
- BT15 Temperature sensor, fluid pipe
- BT16 Temperature sensor, evaporator
- BT17 Temperature sensor, suction gas
- BT28 Temperature sensor, ambient
- BT81 Temperature sensor, injection, EVI compressor
- BT84 Temperature sensor, suction gas evaporator

Electrical components

- AA2 Base card
- CA1 Capacitor (1x230V)
- EB10 Compressor heater
- GQ1 Fan
- QA40 Inverter
- RA1 Harmonic filter (3x400V)
- RA1 Choke (1x230V)
- RF2 EMC filter (3x400V)
- X6 Terminal block (1x230V)

Cooling components

- EP1 Evaporator
- EP2 Condenser
- GQ10 Compressor
- HQ9 Particle filter
- HS1 Drying filter
- QN1 Expansion valve
- QN4 Bypass valve
- QN2 4-way valve
- QN34 Expansion valve, subcooling
- RM1 Non-return valve

Miscellaneous

- PF1 Type plate
- PF3 Serial number
- PF4 Sign, pipe connections
- UB1 Cable gland, incoming supply
- WM5 Condensation water trough

Designations in component locations according to standard IEC 81346-1 and 81346-2.

Distribution box



Electrical components

- AA2 Base card
 - X1 Terminal block, incoming supply
 - X2 Terminal block, compressor supply
 - X5 Terminal block, external control voltage
 - X7 Terminal block, 230V~
 - X9 Terminal block, connection KVR
 - X21 Terminal block, Compressor blocking, Tariff
 - X22 Terminal block, communications
 - X23 Terminal block, communications
 - X24 Terminal block, fan
 - X27 Terminal block, expansion valve QN1
 - X28 Terminal block, subcooling QN34
- F1 Fuse, operating 230V~
- F2 Fuse, operating 230V~
- F3 Fuse for external heating cable KVR
- F4 Fuse, fan
- F5 Fuse, fan
- FC1 Miniature circuit breaker (Replaced with automatic protection (FB1) when installing accessory KVR 10.)

- S1 DIP switch, addressing heat pump during multi operation
- S2 DIP switch, different options
- S3 Reset button

Designations in component locations according to standard IEC 81346-1 and 81346-2.

4 Pipe connections

General

Pipe installation must be carried out in accordance with current norms and directives.

F2120 can only operate up to a return temperature of about 55 $^\circ\rm C$ and an outgoing temperature of about 65 $^\circ\rm C$ from the heat pump.

F2120 is not equipped with external shut off valves on the water side; these must be installed to facilitate any future servicing. The return temperature is limited by the return line sensor.

Water volumes

Depending on the size of F2120, an available water volume is required to prevent short operating times and to enable defrosting. For optimal operation of F2120, a minimum available water volume of 10 litres times the size number is recommended. E.g. F2120-12: 10 litres x 12 = 120 litres.

NOTE

The pipe work must be flushed before the heat pump is connected, so that any contaminants do not damage the components.

Pipe coupling heating medium circuit

- F2120 can be connected to the heating system according to one of the system solutions that can be downloaded from the website www.nibe.eu.
- The heat pump must be vented by the upper connection (XL1) using the venting nipple on the enclosed flexible hose.
- Install the enclosed particle filter before the inlet, i.e. the lower connection (XL2) on F2120.
- All outdoor pipes must be thermally insulated with at least 19 mm thick pipe insulation.
- Install shutoff and drain valves so that F2120 can be emptied in the event of prolonged power failures.
- The supplied flexible hoses act as vibration dampers. The flexible pipes are fitted so an elbow is created, thus acting as vibration damping.

Charge pump

The charge pump (not included in the product) is powered and controlled from the indoor module/control module. It has a built-in anti-freezing function and must therefore not be switched off when there is a risk of freezing.

At temperatures below +2 °C the charge pump runs periodically, to prevent the water from freezing in the charge circuit. The function also protects against excess temperatures in the charge circuit.

Pressure drop, heating medium side

F2120 -8, -12, -16, -20



Heat insulation



Installing flex hoses



5 Electrical connections

General

- The heat pump must not be connected without the permission of the electricity supplier and must be connected under the supervision of a qualified electrician.
- If F2120 is fused with a miniature circuit breaker, it must have at least motor characteristic "C". For MCB size see "Technical Specifications".
- F2120 does not include an omnipolar circuit breaker on the incoming power supply. The heat pump's supply cable must be connected to a circuit breaker with at least a 3 mm breaking gap. When the building is equipped with an earth-fault breaker, the heat pump should be equipped with a separate one. The earth-fault breaker should have a nominal tripping current of no more than 30 mA. Incoming supply must be 400V 3N~ 50Hz via electrical distribution units with fuses.

For 230V~ 50Hz, the incoming supply must be 230V~ 50Hz via distribution box with fuses.

- If an insulation test is to be carried out in the building, disconnect the heat pump.
- If the control is to be supplied separately from other components in the heat pump (e.g. for tariff connection), a separate operating cable must be connected to terminal block (X5).

- The routing of cables for heavy current and signals should be made out through the cable glands on the heat pump's right-hand side, seen from the front.
- The communication cable must be a three core, screened cable and be connected between F2120 terminal block X22 and the indoor module/control module.
- Connect the charge pump to the indoor module/control module. See where the charge pump must be connected in the installation manual for your indoor module/control module.

NOTE

Electrical installation and service must be carried out under the supervision of a qualified electrician. Electrical installation and wiring must be carried out in accordance with the stipulations in force.

NOTE

The live external control must be taken into consideration when connecting.



Accessibility, electrical

connection

Removing the side cover

Unscrew the screws and lift off the cover.



Configuration using dip switch

On the base board (AA2) select the communication address for F2120 against the indoor module / control module. DIP-switch S1 used for configuration of address and functions. For cascade operation with SMO for example, addressing is required. Default has F2120 address **1**. In a cascade connection all F2120 must have a unique address. The address is coded in binary.

DIP S1 position (1 / 2 / 3)	Slave	Address (com)	Default set- ting
off / off / off	Slave 1	01	OFF
on / off / off	Slave 2	02	OFF
off / on / off	Slave 3	03	OFF
on / on / off	Slave 4	04	OFF
off / off / on	Slave 5	05	OFF
on / off / on	Slave 6	06	OFF
off / on / on	Slave 7	07	OFF
on / on / on	Slave 8	08	OFF

DIP S1 posi- tion	Setting	Function	Default set- ting
4	ON	Permits cool-	OFF
		ing	

DIP S2 position	Setting	Default setting
1	OFF	OFF
2	OFF	OFF
3	OFF	OFF
4	OFF	OFF

Switch S3 is the reset button that restarts control.

Caution

DIP S1 position 4 must be changed to ON in order to run cooling

Connections Note To prevent interference, unscreened communication and/or sensor cables to external connections must not be laid closer than 20 cm from high voltage cables. Power connection Incoming supply Incoming sup

Incoming supply cable is enclosed and factory connected to terminal block X1. Outside the heat pump there is approx. 1.8 m of cable available.

At installation, install the screwed connection on the rear of the heat pump. The part of the screwed joint that tensions the cable must be tightened to a tightening torque above 3.5Nm.

e

Connecting external control voltage

NOTE

Mark up any junction boxes with warnings for external voltage.

When connecting external control voltage, remove the bridges from terminal block X5 (see image).

Connect external control voltage (230V~ 50Hz) to terminal block X5:L, X5:N and X5:PE (as illustrated).

If external control voltage is used during tariff control, connect a closing contact to terminal X21:1 and X21:2 (compressor blocking) to prevent an alarm.

External heating cable in condensation water pipe (KVR 10)

F2120 is equipped with a plinth for external heating cable (EB14, not enclosed). The connection is fused with 250 mA (F3) at the factory. If another heating cable is to be used the fuse must be replaced with a suitable one.

Length (m)	Total output (W)	Fuse (F3)	NIBE Part no.
1	15	T100mA/250V	718085
3	45	T250mA/250V	518900*
6	90	T500mA/250V	718086

* Fitted at the factory.

Replace the MCB (FC1) for automatic protection (FB1) when installing KVR 10 if there is no external automatic protection for the installation. Automatic protection (FB1) is available as enclosed component for KVR 10.

Connect external heating cable (EB14) to terminal block X9:L and X9:N. If there is a ground cable connect it to X9:PE. See following image and read further in the installer manual for KVR 10.

NOTE

The pipe must be able to withstand the heat from the heating cable.

To ensure this function the accessory KVR 10 should be used.

Cable routing

The following image shows recommended cable routing from the distribution box to the condensation water trough on the inside of F2120. Transition between the electrical cable and the heating cable must occur after the lead-in to the condensation water trough. The distance between the distribution box and the lead-in to the condensation water trough is approx. 1,600 mm.

Optional connections

Communication

F2120 communicates with NIBE indoor modules/control modules by connecting a three-core, screened cable to terminal block X22:1–4, as shown in the following image.

For cascade connection, join terminal block X23 with X22 to the next heat pump.

VVM

н

SMO 40

|--|

For connection of indoor module/control module, see relevant manual on www.nibe.eu.

Connecting accessories

Instructions for connecting accessories are in the installation instructions provided for the respective accessory. See page 39 for the list of the accessories that can be used with F2120.

6 Commissioning and adjusting

Preparations

- Check that the pipe system is prepared.
- Check the pipe system for leaks.
- Check that the electrical installation is prepared.
- Check that the electrical supply is connected so that the compressor can be warmed up.
- The compressor heater (EB10) must have been active for at least 3 hours before compressor operation can be initiated. This is done by connecting control voltage. F2120 permits compressor start after the compressor has been warmed up. This can take up to 3 hours.

Filling and venting the heating medium system

- 1. Fill the heating medium system to the necessary pressure.
- 2. Vent the system using the venting nipple on the flex hose (enclosed) and possibly the circulation pump.

Start-up and inspection

- 1. Communication cable, terminal block (X22:1-4) must be connected.
- If cooling operation with F2120 is wanted, DIP switch S1 position 4 must be changed according to the description below on page 25.
- 3. Turn the isolator switch on.
- 4. Ensure that the F2120 is connected to the power source.
- 5. Check that fuse (FC1) is on.
- 6. Reinstall the removed panels and cover.
- 7. After the power to F2120 has been switched on and there is a compressor demand from the indoor module/control module, the compressor starts once it has warmed up, after max 180 minutes. The length of this time delay depends on whether the compressor has been warmed up previously. See chapter Preparations on page 31.
- 8. Adjust the charge flow according to size. Also see section "Adjustment, charge flow" on page 32.
- 9. Adjust menu settings via the indoor module/control module as necessary.
- 10. Fill in the commissioning report in the user manual.
- 11. Remove the protective film from the cover on F2120.

NOTE

The external control must be taken into consideration when connecting.

Readjusting, heating medium side

Air is initially released from the hot water and venting may be necessary. If bubbling sounds can be heard from the heat pump, the circulation pump and radiators the entire system will require further venting. When the system is stable (correct pressure and all air eliminated) the automatic heating control system can be set as required.

Adjustment, charge flow

For correct function of the heat pump over the entire year, the charge flow must be correctly adjusted.

If an NIBE indoor module VVM or accessory controlled charge pump is used for the control module SMO, the control tries to maintain an optimal flow across the heat pump.

Adjustment may be required, especially for charging a separate water heater. It is therefore recommended to have the option of adjusting the flow across the water heater using a trim valve.

- 1. Recommendation if there is insufficient hot water and information message "high condenser out" during hot water charging: increase the flow
- 2. Recommendation if there is insufficient hot water and information message "high condenser in" during hot water charging: reduce the flow

7 Control - Introduction

General

F2120 is equipped with an internal electronic controller that handles all functions necessary for operation of the heat pump, e.g. defrosting, stop at max/min temperature, connection of the compressor heater, and protective functions during operation.

Temperatures, number of starts and run time, are read off in the indoor module/control module.

The integrated control shows information via status-LEDs and can be used during servicing.

Under normal operating conditions the home owner does not need to have access to the controller.

F2120 communicates with the NIBE indoor module/control module, which means that all settings and measurement values from F2120 are adjusted and read off on the indoor module/control module.

LED status

The base board (AA2) has six status LEDs for easy control and fault tracing.

LED	State	Explanation
PWR (green)	Not lit	Control board without power
green	Continuous light	Control board power on
CPU	Not lit	CPU without power
(green)	Flashes	CPU running
	Continuous light	CPU running incorrectly
EXT COMM (green)	Not lit	No communication with in- door module/control mod- ule
	Flashes	Communication with in- door module/control mod- ule
INT COMM	Not lit	No communication with in- verter
greeny	Flashes	Communication with invert- er
	Not lit	No defrosting or protection active
(green)	Flashes	Some protection is active
	Continuous light	Defrosting in progress
ERROR	Not lit	No errors
(red)	Flashes	B-alarm, active
	Continuous light	A-alarm, active
K1, K2, K3, K4, K5	Not lit	Relay in de-energised posi- tion
	Continuous light	Relay engaged
N-RELAY		No function

LED	State	Explanation
COMPR. ON		No function

Master control

To control F2120, a NIBE indoor module/control module is required, which calls upon F2120 according to demand. All settings for F2120 are made via the indoor module/control module. It also shows the status and sensor values from F2120.

Description	Value	Paramet- er space	Unit
Cut-out value activation passive defrosting	4	4 – 14	°C
Start temperature BT16 to calculate index	-3	-5 – 5	°C
Permit fan de-icing	No	Yes / No	(1 / 0)
Permit silent mode	No	Yes / No	(1 / 0)
Permit defrost more often	No	Yes / No	(1 / 0)

Control conditions

Control conditions defrosting

- Defrosting occurs actively (with compressor on and fan off) or passively (with compressor off and fan on).
- A time counter counts up every minute if the compressor is running and the temperature of the evaporator sensor (BT16) falls below a threshold value.
- Time until defrosting in minutes appears on the indoor module/control module. Defrosting starts when this value is 0 minutes.
- If "de-icing fan" is activated in menu 5.11.1.1, fan deicing starts during defrosting. De-icing fan prevents the build-up of ice on the fan blades and the front fan grille.
- If the evaporator is too cold, a "safety defrost" starts. This defrosting can be started earlier than when the normal defrosting would start. If 10 safety defrosts in a row occur, an alarm 341 is activated which is a permanent alarm.
- If defrosting is necessary, passive defrosting starts if temperature sensor BT28 is greater than 4 °C and the compressor has stopped because the heating requirement has been met.

Active defrosting:

- 1. The four way valve shifts to defrosting.
- 2. The fan stops and the compressor continues to run.
- When defrosting is complete, the four-way valve switches back to heating operation. The compressor speed is locked for a short period.
- 4. The ambient temperature sensor is locked and the high return temperature alarm is blocked for two minutes after defrosting.

Passive defrosting:

- 1. The compressor stops.
- 2. The four way valve does not shift.
- 3. Fan runs at high speed.
- 4. When passive defrosting is complete, the fan stops.
- 5. The ambient temperature sensor is locked and the high return temperature alarm is blocked for two minutes after defrosting.
- 6. If there is a heat demand, passive defrosting stops and the compressor starts.

There are several possible reasons for an active defrosting to end:

- 1. If the temperature of the evaporator sensor has reached its stop value (normal stop).
- 2. When defrosting has gone on for longer than 15 minutes. This may be due to too little energy in the heat source, too strong a wind effect on the evaporator and/or that the sensor on the evaporator is not correct and therefore displays too low a temperature (at cold outdoor air).
- 3. When the temperature on the return line sensor channel BT3 falls below 10 °C.

4. If the temperature of the evaporator (BP8) falls below its lowest permitted value. After ten failed defrosts, an alarm occurs: 228.

Control - Heat pump EB101

Heat pump menu

Menu 5.11.1.1

These settings are made on the display on the indoor module/control module.

Silent mode permitted

Set whether silent mode is to be activated for the heat pump here. Note that it is possible to schedule when silent mode is to be active.

Detect compressor phase

This shows on which the phase the heat pump has detected whether you have F2120 230V~50Hz. Phase detection normally occurs automatically in connection with start-up of the indoor module/control module. This setting can be changed manually.

Current limit

Set whether the current limiting function is to be activated for the heat pump here. During active function you can limit the value of the maximum current.

Setting range: 6 – 32 A

Factory setting: 32 A

blockFreq 1

Select a frequency range within which the heat pump may work here.

blockFreq 2

Select a frequency range within which the heat pump may work here.

Defrosting

Here you can change the settings that affect the defrost function.

Start temperature for defrost function

Here you can set at which temperature (BT16) the defrost function is to start. The value must only be changed in consultation with your installer.

Setting range: -5 – 5 °C

Factory setting: -3 °C

Cut-out value activation passive defrosting

Here you can set at which temperature (BT28) passive defrosting is to be activated. During passive defrosting, the ice is melted by the energy from the ambient air. The fan is active during passive defrosting. The value must only be changed in consultation with your installer.

Setting range: 2 – 10 °C

Factory setting: 4 °C

Permit defrost more often

Here you activate whether defrosting is to occur more frequently than normal. The selection can be made again if the heat pump receives an alarm due to buildup of ice during operation caused by snow, for example.

Permit fan de-icing

Set whether the "de-icing fan" function is to be activated for the heat pump here. This can be activated if ice/snow accumulates on the fan, grille or fan cone.

8 Disturbances in comfort

Troubleshooting

NOTE

Work behind covers secured by screws may only be carried out by, or under the supervision of, a qualified installation engineer.

NOTE

As F2120 can be connected to a large number of external units, these should also be checked.

NOTE

In the event of action to rectify malfunctions that require work within screwed hatches the incoming electricity must isolated at the safety switch.

NOTE

The alarm is acknowledged on the indoor module/control module (VVM / SMO) or by the voltage to the heat pump being interrupted and then restarted.

The following tips can be used to rectify comfort disruption:

Basic actions

Start by checking the following possible fault sources:

- That the heat pump is running or that the supply cable to F2120 is connected.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The heat pump's miniature circuit breaker (FC1).
- Heat pump's earth-fault breaker.
- F2120 automatic protection (FB1). (Only if KVR 10 is installed.)

Low hot water temperature or a lack of hot water

This part of the fault-tracing chapter only applies if the heat pump is docked to the hot water heater.

- Large hot water consumption.
- Wait until the hot water has heated up.
- Incorrect settings indoor module or control module.
 - See the manual for the indoor module or control module.
- Clogged particle filter.
 - Check whether alarm high condenser out (162) is in the alarm log. Check and clean the particle filter.

Low room temperature

- Closed thermostats in several rooms.
- Set the thermostats to max in as many rooms as possible.
- External switch for changing the room heating activated.
 - Check any external switches.
- Incorrect settings in indoor module or control module.
 - See the manual for the indoor module / control module (VVM / SMO).
- Incorrectly adjusted flow across the heat pump.
 - Check whether alarm high condenser in (163) or high condenser out (162) is in the alarm log. Follow the instructions for adjusting charge flow.

High room temperature

- External switch for changing the room heating activated.
 - Check any external switches.
- Incorrect settings in indoor module or control module.
 - See the manual for the indoor module or control module.

F2120 not in operation

F2120 communicates all alarms to the indoor module/control module (VVM / SMO).

- Ensure that the F2120 is connected to the power source.
- Check the indoor module/control module (VVM / SMO). See section "Disturbances in comfort" in the Installer Manual for the indoor module/control module (VVM / SMO).

F2120 does not communicate

- Check that the addressing of F2120 is correct.
- Check that the communication cable has been connected.

Sensor placement

- BP8 Low pressure transmitter
- BP9 High pressure sensor
- BP11 Pressure sensor, injection
- BT3 Temperature sensor, return
- BT12 Temperature sensor, condenser supply line
- BT14 Temperature sensor, hot gas
- BT15 Temperature sensor, fluid pipe
- BT16 Temperature sensor, evaporator
- BT17 Temperature sensor, suction gas
- BT28 Temperature sensor, ambient
- BT81 Temperature sensor, injection, EVI compressor
- BT84 Temperature sensor, suction gas, evaporator

Data for temperature sensor return line (BT3), condenser supply (BT12), fluid pipe (BT15) and injection (BT81)

Temperature (°C)	Resistance (kOhm)	Voltage (VDC)
-40	351.0	3.256
-35	251.6	3.240
-30	182.5	3.218
-25	133.8	3.189
-20	99.22	3.150
-15	74.32	3.105
-10	56.20	3.047
-5	42.89	2.976
0	33.02	2.889
5	25.61	2.789
10	20.02	2.673
15	15.77	2.541
20	12.51	2.399
25	10.00	2.245
30	8.045	2.083
35	6.514	1.916
40	5.306	1.752
45	4.348	1.587
50	3.583	1.426
55	2.968	1.278
60	2.467	1.136
65	2.068	1.007
70	1.739	0.891
75	1.469	0.785
80	1.246	0.691
85	1.061	0.607
90	0.908	0.533
95	0.779	0.469
100	0.672	0.414

Data for ho	t gas sensor	(BT14)
-------------	--------------	--------

Temperature (°C)	Resistance (kOhm)	Voltage (V)
40	118.7	4.81
45	96.13	4.77
50	78.30	4.72
55	64.11	4.66
60	52.76	4.59
65	43.64	4.51
70	36.26	4.43
75	30.27	4.33
80	25.38	4.22
85	21.37	4.10
90	18.07	3.97
95	15.33	3.83
100	13.06	3.68
105	11.17	3.52
110	9.59	3.36
115	8.26	3.19
120	7.13	3.01
125	6.18	2.84
130	5.37	2.67
135	4.69	2.50
140	4.10	2.33

Data for evaporator sensor (BT16), ambient sensor (BT28), suction gas sensor (BT17) and suction gas, evaporator (BT84)

Temperature (°C)	Resistance (kOhm)	Voltage (VDC)
-50	77.58	4.71
-45	57.69	4.62
-40	43.34	4.51
-35	32.87	4.37
-30	25.17	4.21
-25	19.43	4.03
-20	15.13	3.82
-15	11.88	3.58
-10	9.392	3.33
-5	7.481	3.07
0	6.000	2.80
5	4.844	2.54
10	3.935	2.28
15	3.217	2.03
20	2.644	1.80
25	2.186	1.59
30	1.817	1.39
35	1.518	1.22
40	1.274	1.07
45	1.075	0.93
50	0.911	0.81
55	0.775	0.71
60	0.662	0.62
65	0.568	0.54
70	0.490	0.47
75	0.4233	0.41
80	0.367	0.36
85	0.320	0.32
90	0.280	0.28
95	0.245	0.25
100	0.216	0.22

9 Accessories

Condensation water pipe

Condensation water pipe, different lengths.

KVR 10-10 F2120

1 metres Part no. 067 549 *KVR 10-30 F2120*

3 metres Part no. 067 550

KVR 10-60 F2120

6 metres Part no. 067 551

Control module

SMO 20 Control module Part no. 067 224

SMO 40

Control module Part no. 067 225 Indoor module VVM 310 Part no. 069 430

VVM 310 With integrated EMK 310 Part no. 069 084

VVM320

Copper, 3 x 400 V Part no. 069 108 Stainless Steel, 3 x 400 V Part no. 069 109 Enamel, 3 x 400 V With integrated EMK 300 Part no. 069 110 Stainless Steel, 1 x 230 V Part no. 069 111 Stainless Steel, 1 x 230 V With T&P valve Part no. 069 112 VVM 325

Copper, 3 x 400 V Part no. 069 154

VVM 500 Part no. 069 400

10 Technical data

Dimensions

F2120-8

F2120-12, -16, -20

Sound pressure levels

F2120 is usually placed next to a house wall, which gives a directed sound distribution that should be considered. Accordingly, you should always attempt when positioning to choose the side that faces the least sound sensitive neighbouring area. The sound pressure levels are further affected by walls, bricks, differences in ground level, etc and should therefore only be seen as guide values.

F2120	12	16	20	
Sound power level (L _{WA}), according to EN12102 at 7 / 45	L _W (A)	53	53	53
(nominal)				
Sound pressure level (L _{PA}) at 2 m*	dB(A)	39	39	39
Sound pressure level (L _{PA}) at 6 m*	dB(A)	29.5	29.5	29.5
Sound pressure level (L _{PA}) at 10 m*	dB(A)	25	25	25

*Free space.

Technical specifications

F2120 – 1x230V		8	12
Heating			
Output data according to EN 14511, partial load ¹⁾		1	
7/35 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		3.54 / 0.69 / 5.12
7/45 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		3.64 / 0.91 / 4.00
2/35 Rated output / Supplied power / COP _{FN14511}	kW/kW/-		5.21/ 1.22 / 4.27
2/45 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		5.27 / 1.49 / 3.54
Cooling	Outd. temp: / Supply temp.	Max	Мах
Output data according to EN14511 ∆T5K	35 / 7 °C		4.69 / 1.70 / 2.76
Specified/supplied power/EER	35 / 18 °C		5.44 / 1.73 / 3.15
Electrical data		2201	
Rated voltage		2300	~50HZ
Max operating current, neat pump	A _{rms}		16
Max operating current, compressor	A _{rms}		15
Max output, fan	VV		45
Fuse	A _{rms}		16
Refrigerant circuit			
Type of refrigerant		R4	10A
Type of compressor		Sc	roll
Volume	kg	2.4	2.6
Cut-out value pressure switch HP (BP1)	MPa	4	.5
Difference pressostat HP	MPa	C	.7
Cut-out value pressostat LP	MPa	0.	12
Difference pressostat LP	MPa	C	.7
Brine			
Max airflow	m ³ /h	2,400	3,400
Min/Max air temp, max	°C	-25	/ 43
Defrosting system		revers	e cycle
Hesting modium			
Max system pressure beating medium	MDa		15 bar)
	IVIFa		+.5 Dal)
Man / Min besting medium temp continuous operation	۱/ ۶ °C	0.00/0.52	/ 25
Connection beating medium E2120		G1 1/4" ovtornal	/ 25 throad (025 mm)
Connection heating medium flex nine		G1 1/4" external	thread (Ø35 mm)
		GT 174 external	
Dimensions and weight		1	
Width	mm	1,130	1,280
Depth	mm	610	612
Height with stand	mm	1,070	1,165
Weight (excl. packaging)	kg	150	160

F2120 – 1x230V	8	12	
Miscellaneous			
Enclosure class	IP24		
Colour	gr	ey	
Part No.	064 134	064 136	

F2120 – 3x400V		8	12	16	20
Heating					
Output data according to EN 14511, partial load ¹⁾					
7/35 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		3.54/0.69/5.12	5.17/1.01/5.11	5.17/1.01/5.11
7/45 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		3.64/0.91/4.00	5.49/1.33/4.14	5.49/1.33/4.14
2/35 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		5.21/1.22/4.27	7.80/1.79/4.36	9.95/2.36/4.22
2/45 Rated output / Supplied power / COP _{EN14511}	kW/kW/-		5.27/1.49/3.54	7.97/2.24/3.56	10.41/2.88/3.61
	I		1		
Cooling	Outd. temp: /	Max	Max	Max	Max
	Supply temp.				
Output data according to EN14511 Δ T5K	35 / 7 °C		4.69/1.70/2.76	7.09/2.72/2.61	8.10/3.50/2.31
Specified/supplied power/EER	35 / 18 °C		5.44/1.73/3.15	8.19/2.83/2.90	9.26/3.64/2.54
Electrical data					
Rated voltage			400V 3	N~50Hz	
Max operating current, heat pump	A _{rms}	6	7	9.5	11
Max operating current, compressor	A _{rms}	5	6	8.5	10
Max output, fan	W		45	68	80
Fuse	A _{rms}	10	10	10	13
Refrigerant circuit					
Type of refrigerant		R410A			
Type of compressor		Scroll			
Volume	kg	2.4	2.6	3	3
Cut-out value pressure switch HP (BP1)	MPa		4	.5	
Difference pressostat HP	MPa	0.7			
Cut-out value pressostat LP	MPa	0.12			
Difference pressostat LP	MPa		0	.7	
Airflow	2 (1	2.400	2.400	4.450	4 5 0 0
Max airflow	m³/h	2,400	3,400	4,150	4,500
Min/Max air temp, max	تر		-25	/ 43	
Water flow					
Max system prossure beating medium	MPo		0.45.(/	15 har)	
Min/Max flow	1/r	0.08/0.32			0 19/0 75
Min flow defrosting (100 % nump speed)	/s	0.0070.32	0.1170.44	0.13/0.00	0.1370.73
Max/Min beating medium temp continuous operation	°C	0.27	65	/ 25	0.40
Connection heating medium F2120		G1 1.	/4" external	thread (Ø35	imm)
Connection heating medium flex pipe		G1 1	/4" external	thread (Ø35	imm)
Dimensions and weight					
Width	mm	1,130		1,280	
Depth	mm	610		612	
Height with stand	mm	1,070		1,165	
Weight (excl. packaging)	kg	167	177	. 18	33
		ı <u></u> .	·	ı	

F2120 – 3x400V		8 12 16 20			
Miscellaneous					
Defrosting system		revers	e cycle		
Enclosure class	IP24				
Colour	Grey				
Part No.	064 135	064 137	064139	064 141	

SCOP & Pdesign F2120 according to EN 14825								
F2120	8	3	1	2	1	6	2	0
	Pdesign	SCOP	Pdesign	SCOP	Pdesign	SCOP	Pdesign	SCOP
SCOP 35 Average cli-			8	4.83	11	5.05	11	5.05
mate (Europe)								
SCOP 55 Average cli-			8.3	3.78	12.3	3.9	12.3	3.9
mate (Europe)								
SCOP 35 Cold climate			9.3	4.05	13	4.25	13	4.25
SCOP 55 Cold climate			9.8	3.33	14	3.53	14	3.53
SCOP 35 Warm climate			9.2	5.48	13	5.5	13	5.5
SCOP 55 Warm climate			9.2	4.48	13	4.5	13	4.5

¹⁾Power statements including defrosting according to EN14511 at heating medium supply corresponding to DT=5 K at 7 / 45. ²⁾Nominal flow corresponds to DT=10 K at 7 / 45.

During shorter time it is allowed to have lower working temperatures on the water side, e.g. during start up.

Heating

Output and COP at different supply temperatures

F2120-12

F2120-16 Max. heating capacity °C supply temperature Heating capacity (kW) 14 13 12 11 10 4-25 -20 Outdoor temperature (°C F2120-16 COP °C supply temperature COP 6,00 5,00 4,00 3,00 2.00 1,00 0,00 -20 -15 -10 10 15 Outdoor temperature (°C)

F2120-16

0_____

-20

-15

-10

10

Outdoor temperature (°C)

15

F2120-20

Cooling

Output at different supply temperatures (cooling)

F2120-12

F2120-20

F2120-16

Energy labelling

Information sheet

Supplier			NIBE	
Model		F2120-12	F2120-16	F2120-20
Model hot water heater		VVM 320	VVM 500	VVM 500
Temperature application	°C	35 / 55	35 / 55	35 / 55
Declared load profile for water heating		XL	XXL	XXL
Seasonal space heating energy efficiency class, average climate		A++ / A++	A++ / A++	A++ / A++
Water heating energy efficiency class, average climate		Α	Α	Α
Rated heat output (Pdesignh), average climate	kW	8.0 / 8.3	11.0 / 12.3	11.0 / 12.3
Annual energy consumption space heating, average climate	kWh	8,3	12,3	12,3
Annual energy consumption water heating, average climate	kWh	1661	2096	2096
Seasonal space heating energy efficiency, average cli- mate	%	190 / 148	199 / 153	199 / 153
Water heating energy efficiency, average climate	%	101	103	103
Sound power level L _{WA} indoors	dB	35	35	35
Rated heat output (Pdesignh), cold climate	kW	9.3 / 9.8	13.0 / 14.0	13.0 / 14.0
Rated heat output (Pdesignh), warm climate	kW	9.2 / 9.2	13.0 / 13.0	13.0 / 13.0
Annual energy consumption space heating, cold cli- mate	kWh	5,666 / 7,239	7,543 / 9,765	7,543 / 9,765
Annual energy consumption water heating, cold cli- mate	kWh	1895	2284	2284
Annual energy consumption space heating, warm cli- mate	kWh	2,241 / 2,741	3,153 / 3,867	3,153 / 3,867
Annual energy consumption water heating, warm climate	kWh	1473	1873	1873
Seasonal space heating energy efficiency, cold climate	%	159 / 130	167 / 138	167 / 138
Water heating energy efficiency, cold climate	%	88	94	94
Seasonal space heating energy efficiency, warm cli- mate	%	216 / 176	217 / 177	217 / 177
Water heating energy efficiency, warm climate	%	114	115	115
Sound power level L _{WA} outdoors	dB	53	53	53

Data for energy efficiency of the package

Model		F2120-12	F2120-16	F2120-20	
Model hot water heater		VVM 320	VVM 500	VVM 500	
Temperature application	°C	35 / 55	35 / 55	35 / 55	
Controller, class			VI		
Controller, contribution to efficiency	%	4.0			
Seasonal space heating energy efficiency of the pack- age, average climate	%	194 / 152	203 / 157	203 / 157	
Seasonal space heating energy efficiency class of the package, average climate		A+++ / A+++	A+++ / A+++	A+++ / A+++	
Seasonal space heating energy efficiency of the pack- age, cold climate	%	163 / 134	171 / 142	171 / 142	
Seasonal space heating energy efficiency of the pack- age, warm climate	%	220 / 180	221 / 181	221 / 181	

The reported efficiency of the package also takes the controller into account. If an external supplementary boiler or solar heating is added to the package, the overall efficiency of the package should be recalculated.

Technical documentation

Model			F2120-12						
Model hot water heater			VVM 320						
Type of heat pump		🛛 Air-v	vater						
		🔲 Exha	ust-water						
		Brine	e-water						
		U Wate	er-water						
Low-temperature heat pump									
Integrated immersion heater for additional heat									
Heat pump combination heater		X Yes							
Climate			Average Cold Warm						
Temperature application			☑ Average (55 °C) □ Low (35 °C)						
Applied standards			EN14825 / EN14511 / EN16147 / EN12102						
Rated heat output	Prated	8,3	kW	Seasonal space heating energy efficiency	η	148	%		
Declared capacity for space heating at part load Ti	and at out	door tem	perature	Declared coefficient of performance for space heating at part load and at outdoor temperature Ti					
Tj = -7 °C	Pdh	7.3	kW	Tj = -7 °C	COPd	2.39	-		
Tj = +2 °C	Pdh	4.7	kW	Tj = +2 °C	COPd	3.85	-		
Tj = +7 °C	Pdh	2.9	kW	Tj = +7 °C	COPd	4.48	-		
Tj = +12 °C	Pdh	3.3	kW	Tj = +12 °C	COPd	5.30	-		
Tj = biv	Pdh	7.3	kW	Tj = biv	COPd	2.39	-		
Tj = TOL	Pdh	7.8	kW	Tj = TOL	COPd	2.28	-		
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	Tj = -15 °C (if TOL < -20 °C)	COPd		-		
Bivalent temperature	Tu	-7	ଂ	Min outdoor air temperature	TOI	-10	°C		
Cycling interval capacity	Pcych		kW/	Cycling interval efficiency	COPeye		-		
Degradation coefficient	Cdh	0.99	-	Max supply temperature	WTOI	65	°C		
	can	0.55							
Power consumption in modes other than active mode				Additional heat					
Off mode	POFF	0.025	kW	Rated heat output	Psup	0.5	kW		
Thermostat-off mode	P _{TO}	0.007	kW						
Standby mode	P _{SB}	0.025	kW	Type of energy input		Electric			
Crankcase heater mode	P _{CK}	0.037	kW						
Other items									
Capacity control		Variable		Rated airflow (air-water)		3,400	m ³ /h		
Sound power level, indoors/outdoors	L _{WA}	35 / 53	dB	Nominal heating medium flow		,	m³/h		
Annual energy consumption	Q _{HE}	4,529	kWh	Brine flow brine-water or water-water heat pumps			m³/h		
For heat pump combination heater				1					
Declared load profile for water heating		XL		Water heating energy efficiency	η _{wh}	101	%		
Daily energy consumption	Q _{elec}	7.56	kWh	Daily fuel consumption	Q _{fuel}		kWh		
Annual energy consumption	AEC	1,661	kWh	Annual fuel consumption	AFC		GJ		

Model				F2120-16					
Model hot water heater			VVM 500						
Type of heat pump		🛛 Air-w	vater						
		Exha	ust-water						
		Brine	-water						
		Wate	er-water						
Low-temperature heat pump									
Integrated immersion heater for additional heater	at	Ves							
Heat pump combination heater		Yes							
Climate		🛛 Average 🔲 Cold 🔲 Warm							
Temperature application			☑ Average (55 °C) □ Low (35 °C)						
Applied standards			EN14825 / EN14511 / EN16147 / EN12102						
Rated heat output	Prated	12,3	kW	Seasonal space heating energy efficiency	η	153	%		
Declared capacity for space heating at part loac Ti	and at ou	tdoor tem	perature	Declared coefficient of performance for space heating at part load and at outdoor temperature Ti					
Tj = -7 °C	Pdh	10.9	kW	Tj = -7 °C	COPd	2.48	-		
$T_j = +2 °C$	Pdh	6.7	kW	Tj = +2 °C	COPd	3.96	-		
Tj = +7 °C	Pdh	5.9	kW	Tj = +7 °C	COPd	4.67	-		
Tj = +12 °C	Pdh	6.5	kW	Tj = +12 °C	COPd	5.67	-		
Tj = biv	Pdh	10.9	kW	Tj = biv	COPd	2.48	-		
Tj = TOL	Pdh	11.6	kW	Tj = TOL	COPd	2.40	-		
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	Tj = -15 °C (if TOL < -20 °C)	COPd		-		
Rivelent temperature	т	7	°C	Min, outdoor air tomporatura	TO	10	°۲		
Cycling interval capacity	Povch	- /			COPeyre	-10	C		
	Cdb	0.99	K V V	Max supply temperature	WTOI	65	- °C		
	Curr	0.55	-		VVIOL	05	C		
Power consumption in modes other than active	mode			Additional heat					
Off mode	Porr	0.025	kW	Rated heat output	Psup	0.7	kW		
Thermostat-off mode	PTO	0.007	kW						
Standby mode	Pcp	0.025	kW	Type of energy input		Flectric			
Crankcase heater mode	Per	0.037	kW						
Other items	CK								
Capacity control		Variable		Rated airflow (air-water)		4,150	m ³ /h		
Sound power level, indoors/outdoors	L _{WA}	35 / 53	dB	Nominal heating medium flow			m³/h		
Annual energy consumption	Q _{HE}	6,524	kWh	Brine flow brine-water or water-water heat			m³/h		
		1		r . r .		I	<u> </u>		
For heat pump combination heater		VVI	1	Water heating energy officiency	n	102	0/		
			k\A/b	Daily fuel concumption	Hwh	103	-70 k\//h		
		3.54	KVVII k\A/b						
Annual energy consumption	AEC	2,090	KVVII		AFC		נט		

53

Model hot water heater VVM 500 Type of heat pump				
Type of heat pump Air-water Exhaust-water Brine-water Water-water Water-water Low-temperature heat pump Yes No Integrated immersion heater for additional heat Yes No Heat pump combination heater Yes No Climate Average Cold Warm Temperature application Average (55 °C) Low (35 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102				
Exhaust-water Brine-water Water-water Low-temperature heat pump Yes Integrated immersion heater for additional heat Yes Heat pump combination heater Yes Keater No Climate Average Temperature application Average (55 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102				
Brine-water Water-water Low-temperature heat pump Yes Integrated immersion heater for additional heat Yes Heat pump combination heater Yes Kest No Climate Average Temperature application Average (55 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102				
Image: Solute Water Low-temperature heat pump Integrated immersion heater for additional heat Integrated immersion heater Image: Solute Water Heat pump combination heater Image: Solute Water Image: Solute Water<				
Low-temperature heat pump Yes No Integrated immersion heater for additional heat Yes No Heat pump combination heater Yes No Climate Average Cold Warm Temperature application Average (55 °C) Low (35 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102				
Integrated immersion heater for additional heat Yes No Heat pump combination heater Yes No Climate Average Cold Warm Temperature application Average (55 °C) Low (35 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102	153 04			
Heat pump combination heater Image: Cold ima	153 %			
Climate Average Cold Warm Temperature application Average (55 °C) Low (35 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102	153 %			
Temperature application Average (55 °C) Low (35 °C) Applied standards EN14825 / EN14511 / EN16147 / EN12102	153 %			
Applied standards EN14825 / EN14511 / EN16147 / EN12102	153 %			
	153 %			
Rated heat output Prated 12,3 kW Seasonal space heating energy efficiency η_s	/0			
Declared capacity for space heating at part load and at outdoor temperature Declared coefficient of performance for space heating at part outdoor temperature Ti	Declared coefficient of performance for space heating at part load and at outdoor temperature Ti			
$Ti = -7 \degree C \qquad Pdh 10.9 kW Ti = -7 \degree C \qquad COPd 2$	2.48 -			
$T_j = +2 \degree C$ Pdh 6.7 kW $T_j = +2 \degree C$ COPd 3	3.96 -			
Tj = $+7 \degree C$ Pdh 5.9 kW Tj = $+7 \degree C$ COPd 4	4.67 -			
Tj = +12 °C Pdh 6.5 kW Tj = +12 °C COPd 5	5.67 -			
Tj = biv Pdh 10.9 kW Tj = biv COPd 2	2.48 -			
Tj = TOL Pdh 11.6 kW Tj = TOL COPd 2	2.40 -			
Tj = -15 °C (if TOL < -20 °C) Pdh kW Tj = -15 °C (if TOL < -20 °C) COPd	-			
Rivalent temperature T7 °C Min outdoor air temperature TOL	-10 °C			
Cycling interval capacity Provch kW Cycling interval efficiency COPovc	-10 C			
Degradation coefficient Cdb 0.99 - Max supply temperature WTO	65 °C			
	05 0			
Power consumption in modes other than active mode Additional heat				
Off mode P _{OFF} 0.025 kW Rated heat output Psup	0.7 kW			
Thermostat-off mode P _{TO} 0.007 kW				
Standby mode P _{SB} 0.025 kW Type of energy input Ele	ectric			
Crankcase heater mode P _{CK} 0.037 kW				
Other items				
Capacity control Variable Rated airflow (air-water) 4	.150 m ³ /h			
Sound power level, indoors/outdoors L _{MA} 35 / 53 dB Nominal heating medium flow	m³/h			
Annual energy consumption Q _{HE} 6,524 kWh Brine flow brine-water or water-water heat	m ³ /h			
pumps				
For heat pump combination heater				
Declared load profile for water heating XXL Water heating energy efficiency η_{wh}	103 %			
Daily energy consumption Q _{elec} 9.54 kWh Daily fuel consumption Q _{fuel}	kWh			
Annual energy consumption AEC 2,096 kWh Annual fuel consumption AFC	GJ			

Electrical circuit diagram 1x230V

3x400V

11 Item register

Item register

A

Accessories, 39 Addressing via multi-heat pump operation, 25 Adjustment, charge flow, 32 Assembly, 10

В

Balance temperature, 4

C

Charge pump, 21 Commissioning and adjusting, 31 Adjustment, charge flow, 32 Balance temperature, 4 Compressor heater, 4 Filling and venting the heating medium system, 31 Preparations, 31 Readjusting, heating medium side, 31 Start-up and inspection, 31 Stop temperature, 4 Communication, 29 Compressor heater, 4 Connecting accessories, 30 Connecting external control voltage, 27 Connections, 26 Connecting external control voltage, 27 Contact information, 9 Control. 33 Control - Introduction, 33 Control conditions, 34 Control conditions defrosting, 34 Control - Heat pump EB101, 35 Control - Introduction, 33 Control conditions, 34 Control conditions defrosting, 34 Control - Heat pump EB101, 35 General, 33 LED status, 33 Master control, 33

D

Delivery and handling, 10 Assembly, 10 Installation area, 14 Removing the side cover, 15 Supplied components, 14 Transport and storage, 10 Dimensions and setting-out coordinates, 40 Disturbances in comfort, 36 Troubleshooting, 36

Ε

Electrical cabinet, 20 Electrical circuit diagram, 55 Electrical connections, 23 Addressing via multi-heat pump operation, 25 Connecting accessories, 30 Connections, 26 General, 23 Optional connections, 29 Power connection, 26 Energy labelling, 51 Data for energy efficiency of the package, 51 Information sheet, 51 Technical documentation, 52

F

Filling and venting the heating medium system, 31

I.

Important information, 4 Recovery, 4 Safety information, 4 Inspection of the installation, 8 Installation area, 14

L LED status, 33

М

Marking, 4 Master control, 33

0

Optional connections, 29 Communication, 29

Ρ

Pipe connections, 21 Charge pump, 21 General, 21 Pipe coupling heating medium circuit, 21 Pressure drop, heating medium side, 21 Water volumes, 21 Pipe coupling heating medium circuit, 21 Power connection, 26 Preparations, 31 Pressure drop, heating medium side, 21

R

Readjusting, heating medium side, 31 Removing the side cover, 15

S

Safety information, 4 Contact information, 9 Inspection of the installation, 8 Marking, 4 Safety precautions, 6 Serial number, 4 Symbols, 4 Safety precautions, 6 Sensor placement, 37 Serial number, 4 Sound pressure levels, 41 Start-up and inspection, 31 Stop temperature, 4 Supplied components, 14 Symbols, 4

Т

Technical data, 40 Dimensions and setting-out coordinates, 40 Electrical circuit diagram, 55 Sound pressure levels, 41 Technical Data, 42 Technical Data, 42 The heat pump design, 16 Component list electrical cabinet, 20 Component location electrical cabinet, 20 Component locations, 16 List of components, 16, 19 Transport and storage, 10 Troubleshooting, 36 Sensor placement, 37

NIBE AB Sweden Hannabadsvägen 5 Box 14 SE-285 21 Markaryd info@nibe.se www.nibe.eu

